



## **Gyro Compass Equipment STANDARD 20 COMPACT with Speed-error Correction**

**consisting of:**

- **Gyro Compass STANDARD 20**  
**Type 110 - 800 or 110 - 806**
- **Distributor COMPACT, Type 110 - 224 NG002**
- **Operator Unit STANDARD 20, Type 130 - 601 E01**
- **Repeater Compass, Type 133 - 555 or 133 - 556 (analog)**  
**Type 133 - 811 (digital)**

## **OPERATOR MANUAL**

Weitergabe sowie Vervielfältigung dieser Unterlage, Verwertung und Mitteilung ihres Inhaltes nicht gestattet, soweit nicht ausdrücklich zugestanden. Zu widerhandlungen verpflichten zu Schadenersatz.

*Toute communication ou reproduction de ce document, toute exploitation ou communication de son contenu sont interdites, sauf autorisation expresse. Tout manquement à cette règle est illicite et expose son auteur au versement de dommages et intérêts.*

*Copying of this document, and giving it to others and the use or communication of the contents thereof, are forbidden without express authority. Offenders are liable to the payment of damages.*

*Sin nuestra expresa autorización, queda terminantemente prohibida la reproducción total o parcial de este documento, así como su uso indebido y/o su exhibición o comunicación a terceros. De los infractores se exigirá el correspondiente resarcimiento de daños y perjuicios.*



## CONTENTS

## Page

### Safety Regulations

### Declaration of Conformity acc. to EC Directive 96/98/EC

1	Application .....	1
1.1	Function of the Devices belonging to the Equipment .....	2
2	General .....	3
3	Notes on the Operating Instructions .....	4
4	Switching-on and off .....	5
4.1	Switching-on .....	5
4.2	Switching-off .....	6
5	Measures to be Taken before Commencing a Voyage and during the Voyage ..	7
6	Putting into Operation .....	9
6.1	Possibility of Calling up the Momentary Supporting Liquid Temperature ..	12
6.2	Possibility of Calling up the Previous Settling Time .....	12
6.3	Operating Instructions with Normal Operation .....	13
6.3.1	Switching-over from Automatic to Manual Reference Value Input for the Speed-error Correction .....	13
6.3.1.1	Reference Value for Latitude (Lat.) .....	13
6.3.1.2	Reference Value for Speed (Spd.) .....	14
6.3.2	Switching-over from Manual to Automatic Reference Value Input for the Speed-error Correction .....	16
6.3.2.1	Reference Value for Latitude (Lat.) .....	16
6.3.2.2	Reference Value for Speed (Spd.) .....	17
6.4	Additional Operations in Normal Mode .....	19
6.4.1	Calling up the Uncorrected Heading Value .....	19
6.4.2	Calling up the Current Reference Values (Lat. und Spd.) .....	19
6.4.3	Dimming .....	20
6.4.4	Contrast Adjustment of the LCD Display .....	20
6.4.5	Test .....	20
6.5	Warnings by Events at the Gyro Compass .....	21

# Gyro Compass Equipment STANDARD 20 COMPACT

## with Speed-error Correction

### Operator Manual

---

7	Fault Operation .....	23
7.1	Survey of Alarms on the Components of the Equipment .....	23
7.2	Procedure in Case an Alarm occurs .....	24
7.2.1	Survey of Alarms .....	25
7.2.2	Fault List .....	27

## Annex

### Safety Regulations:




#### Automatic Reference Value Input:

- For an optimal speed-error correction the reference values of the sensors must be correct.  
Before switching-over to automatic reference value input operating mode, the sensor values must therefore be checked.

#### Manual Reference Value Input:

- For an optimal speed-error correction, the reference values must continually be adapted to the current situation.  
If there are no compulsive reasons for a manual reference value input (e.g. breakdown in sensor/sensor not available), then automatic reference value input must **always** be selected.

**When switching-over from automatic to manual reference value input, a heading displacement may occur on the heading receivers connected. Therefore check, whether a new set heading must be entered to the autopilot (exception Autopilot Version NP 2000)!**



## 1

### Application


The gyro compass equipment STANDARD 20 COMPACT is used for navigation on board ships.

The gyro compass STANDARD 20 as a sensor ascertains true north independently from the earth's magnetic field and, thus, permits steering of a heading referred to geographical north.

The heading signal from the absolute, digital position pick-off in the gyro compass STANDARD 20 undergoes an internal digital processing.

The heading signal made available by the gyro compass includes a physically-conditioned speed error. Furthermore, in case of speed and heading changes, there occurs a slight compass error which is caused by the distribution of the damping oil (oil-damping residual error). In the distributor COMPACT, therefore, the heading signal undergoes the required correction. All values required for the correction (speed and latitude) are automatically or manually entered via an operator unit.

Built-in transmission systems ensure heading transmission to repeater compasses and further reference receivers.



**Fig. 1:** Gyro Compass Equipment STANDARD 20 COMPACT

### Operator Manual

This operator manual contains all operating instructions as well as a survey of possible warnings and alarms indicated on the digital display.

### Service Manual

In addition to the operator manual a service manual is available. It contains informations about installation and first putting into operation.

**Gyro Compass Equipment STANDARD 20 COMPACT**  
**with Speed-error-Correction**  
**Operator Manual**


---

**1.1**

**Function of the Devices belonging to the Equipment**

- Gyro Compass STANDARD 20, Type 110 – 800 or 110 – 806 (without casing for installation in the steering stand ComPilot 20)  
(see Description No. 2771E/110–800.DOC012)
  - Determination of "true north"
  - Indication of ship's heading – referred to "true north" – via a digital display
  - Transmission of the heading signals to the connected reference receivers via the distributor COMPACT
- Repeater Compass, Type 133 – 555/556 or Type 133 – 811  
(see also Description No. 133–555.E03.DOC012 or 133–556.DOC012 or 133–811.DOC012, resp.)
  - Indication of the gyro compass heading, analog and/or digital
  - Digital display of errors and alarms within the repeater compass
  - Synchronization of the analog indication according to the digital display  
(Type 133–555/556 only)
- Distributor COMPACT, Type 110 – 224 NG002  
(see also Description No. 110–224.NG002.DOC032)
  - Supply of gyro compass STANDARD 20 with the required voltages
  - Conversion of the information – serially received via the serial interface RS 422 (heading, R.o.T.) – into signals for the steering repeater connected
  - Correction of speed and oil-damping residual error for the heading signal of the gyro compass
  - Passing-on of the serial interface RS 422 "HEADING SERIAL" \*)
  - Fusing of the supply for connected loads (digital repeaters, steering repeater or SPERRY step loads)
- Operator Unit STANDARD 20 PLUS, Type 130 – 601
  - Digital display of the corrected and uncorrected gyro compass heading
  - Digital display of the current state of the system
  - Indication of errors and alarms within the complete system
  - Possibility of manual input of speed and latitude (for speed–error correction)

\*) Raytheon Marine specific



## 2

### General

The construction and contents of this instruction manual have been adapted to the system configuration delivered.

The instructions comprise the following

- configuration-neutral notes and operation instructions in Sections 2 to 5
- the operation of the gyro compass equipment STANDARD 20 COMPACT with connected gyro compass via the Operator Unit Type, 130-601, Compass Operating Instructions, Section 6

These operating instructions contain all operations in normal operation as well as in fault operation for all operations carried out via this operator unit.

In general, therefore, help from the equipment manuals is not necessary; in special cases these are referred to.

It is recommended to fold out the pages of the Annex; all operating elements and indications are represented here.

The following equipment operations are not integrated into these instructions:

- Log
- Position receiver

**Gyro Compass Equipment STANDARD 20 COMPACT**  
with Speed-error-Correction  
Operator Manual

**3**

**Notes on the Operating Instructions**

The operation is interactive (action ⇒ reaction).

Operating modes are defined acc. to Fig. 2. To change to a desired operating mode or for other additional operations, the operating procedure shown in the corresponding chapter is to be followed step by step. When necessary, helpful information in short form has been added to the figurative representation (symbols).

Explanation of symbols:



Key operation




Action, general



LED *out*



LED *on*




LED *flashing*



Audible signal *on*



Audible signal *off*



---

## 4      **Switching-on and off**


### 4.1    **Switching-on**

- With connecting the 24 V voltage supply, the gyro compass equipment is put into operation.  
The central Distributor COMPACT, Type 110 – 224 NG002, distributes the supply voltage for
  - Gyro compass
  - Operator unit STD 20
  - Repeaters
- To be separately switched on are (refer to corresponding individual equipment manuals)
  - Log
  - Position receiver

The equipment is automatically in the operating mode that was selected before switching off (with the exception of an initial start). Dependent on the system configuration, this could mean the following when in normal operation (refer to Fig. 2):

- Gyro compass operation with automatic reference value input for the speed-error correction.
- Gyro compass operation with manual reference value input for the speed-error correction.

# Gyro Compass Equipment STANDARD 20 COMPACT with Speed-error Correction Operator Manual




**Fig. 2:** Operating Conditions / Operating Modes in Gyro Compass Operation.  
Chapter numbers refer to corresponding operating sequences

## 4.2 Switching-off

The system (see listing in Section 4.1) is put out of operation by switching off the 24V power supply.



Do not switch off the gyro compass equipment without reason!  
Settling time approx. 3 to 5 hours.




## 5 Measures to be Taken before Commencing a Voyage and during the Voyage

Con. No.	Measure	Chapter No.	Measure Taken		Comments
			before voyage	during voy- age	
1	Check of the operating and indicating units with the test function	6.4.5	x	as required	
2	Check of the reference values of the position receiver and correctness of the log	6 [2] and [3]	x	as required	
3	Check of correctness of heading value of the gyro compasses	6.4.1	x	as required	Comparison of uncorrected heading value at operator unit with gyro compass display Comparison of values gyro compass – magnetic compass
4	Check whether operating mode <b>Aut</b> (for <b>Lat</b> and <b>Speed</b> ) has been selected	6.3.2	x	-	If the system configuration and system condition allow it, this operating mode should always be selected
5	Check whether equipment is in fault operation	7	x	as required	Refers to current alarm that is acknowledged but still waiting apply applicable measures
6	Check whether equipment is free of current warnings	6.5	x	as required	Remove cause in order to avoid possible breakdown later
7	Check whether repeaters are in fault operation	7.1	x	as required	Refer to equipment manual 'Repeater Compass', 133-555.DOC012 or 133-556.DOC012
8	Check whether digital and analog displays at repeater are in agreement		x	daily	Compare the card display with the digital display Synchronize if necessary
9	In operating mode <b>Man</b> , adaptation of the reference values to the current situation	6.3.1 [2], [3], [4]	x	as required	

**Gyro Compass Equipment STANDARD 20 COMPACT**  
**with Speed-error-Correction**  
**Operator Manual**

---







## 6


### Putting into Operation

	<b>Indications</b>	<b>Comments, Notes</b>
<b>[1]</b> <b>Switching-on the 24 V Navigation or Power Supply (refer to Section 4.1)</b>	<p><b>G1: Heating</b></p> <p><b>Gyro compass:</b></p> <p><b>Repeater compass:</b></p>	<p>Adopted operation mode after switching-on: Gyro compass operation with automatic reference value input for speed-error correction.</p> <p>Gyro compass in the heating phase</p> <p>Display of temperature of supporting liquid in °C</p>
<b>[2]</b> <b>Checking the Reference Values for Latitude (Lat.)</b>	<p><b>Aut Lat.: 51° 12'</b> <b>use Set / Lat</b></p>	<p>Check the correctness of the reference values at all costs, otherwise speed-error correction cannot be guaranteed! (Refer also to 6.4.2)</p> <p><b>1<sup>st</sup> line:</b> – current reference value of the sensors</p> <p>Confirm correct reference values with key <b>Set</b>; otherwise, switch-over to manual value input. (refer to 6.3.1)</p>

**Gyro Compass Equipment STANDARD 20 COMPACT**  
**with Speed-error Correction**  
**Operator Manual**

---

	<b>Indications</b>	<b>Comments, Notes</b>
 	  	<p>Check the correctness of the reference values at all costs, otherwise speed-error correction cannot be guaranteed!          (Refer also to 6.4.2)</p> <p>1<sup>st</sup> line:          – current reference value of the sensors</p> <p>Confirm correct reference values with key <b>Set</b>; otherwise, switch-over to manual value input.          (refer to 6.3.1)</p>
		<p>After reaching the lower operating temperature of 45 °C, automatic display of the heading value</p> <div style="border: 1px solid black; padding: 5px; margin-top: 10px;">             Heading value still imprecise and not usable!         </div> <p>Gyro compass:</p>  <p>Repeater compass:</p> <p>○ (yellow)</p>  <p>Additional point signalizes:          Settling procedure not yet completed</p>




	Indications	Comments, Notes
<b>5</b> Automatical Display of the Valid, <u>Corrected</u> Heading Value		
	<p>G1: 131.8</p> <p>Gyro compass:</p> <p>132.3</p> <p>Repeater compass: <input type="radio"/> (green) 13 1.8</p>	<p>Gyro compass is ready for operation after approx. 3 hrs. settling time from now, display of valid, <u>corrected</u> heading value of gyro compass</p> <p>Accuracy: After approx. 3 hrs.: better 2° After approx. 5 hrs.: better <math>0.1^\circ \times \frac{1}{\cos \text{latitude}}</math></p> <p>Display of the uncorrected (!) heading on the gyro compass</p> <p>Display of the corrected heading</p>

**Gyro Compass Equipment STANDARD 20 COMPACT**  
**with Speed-error-Correction**  
**Operator Manual**

---

**6.1**

**Possibility of Calling up the Momentary Supporting Liquid Temperature**

	<b>Indications</b>	<b>Comments, Notes</b>
	<p>Temperat. 42.3°C</p> <p>Gyro compass:              Heating phase</p> <p>Repeater compass:    </p>	<p>Can be performed only in the time between switching-on 6 ① and automatic heading indication 6 ④ (heating phase)</p> <p>Display of the supporting liquid temperature whilst pressing the key</p> <p>Display of the supporting liquid temperature in °C</p>

**6.2**

**Possibility of Calling up the Previous Settling Time**

	<b>Indications</b>	<b>Comments, Notes</b>
	<p>Not Settled 1.4h</p>	<p>Can be performed only in the time between automatic heading indication 6 ④ and automatic indication of the valid, corrected heading value 6 ⑤ (settling time)</p> <p>Display of the previous settling time whilst pressing the key</p>



## 6.3 Operating Instructions with Normal Operation

### 6.3.1 Switching-over from Automatic to Manual Reference Value Input for the Speed-error Correction



For an optimal speed-error correction, the reference values must continually be adapted to the current situation.



If there are no compulsive reasons for a manual reference value input (e.g. breakdown in sensor/sensor not available), then automatic reference value input must **always** be selected.

**Important Note:**

**When switching-over from automatic to manual reference value input, a heading displacement may occur on the heading receivers connected.**

**Therefore check, whether a new set heading must be entered to the autopilot (exception Autopilot Version NP 2000)!**



#### 6.3.1.1 Reference Value for Latitude (Lat.)


	Indications	Comments, Notes
[1] Calling up the Current Mode of Operation	 	<p>1<sup>st</sup> line:        - Current reference value of the position receiver</p> <p>2<sup>nd</sup> line:        - Request to switch-over to manual value input (refer to [2]) or to remain in the automatic value input (<b>Set</b> key)</p>
[2] Switching-over the Operating Mode	 	<p>1<sup>st</sup> line:        - Last manually entered reference value</p> <p>2<sup>nd</sup> line:        - Request to accept the displayed value (refer to [4]) or to accept a new value (refer to [3] and [4])</p>
[3] Changing values	 or:  <p>Limit values 'Lat.'        upper: 85° 00'        lower: 00° 00'</p>	<p>Changing values (can be read-off at LCD display):</p> <ul style="list-style-type: none"> <li>- stepwise by short actuation</li> <li>- continually by long actuation</li> </ul> <p>If, after 7 s, these keys or the key <b>Set</b> are not actuated, then the yellow LED goes out and the system returns to its initial condition.</p> <p>Values outside of the limit values cannot be set.</p>

**Gyro Compass Equipment STANDARD 20 COMPACT**  
**with Speed-error Correction**  
**Operator Manual**

	<b>Indications</b>	<b>Comments, Notes</b>
[4] Accepting Values	  <div style="border: 1px solid black; padding: 5px; display: inline-block;"> G1: 153.7° Man </div>	<p>Accepting values and thereby switching-over to manual reference value input for the speed-error correction</p> <p>Indication of the current, corrected heading value of the gyro compass.</p> <p><b>Man</b> signalizes selection of the manual reference value input.</p>

#### 6.3.1.2 Reference Value for Speed (Spd.)

	<b>Indications</b>	<b>Comments, Notes</b>
[1] Calling up the Current Mode of Operation	 <div style="border: 1px solid black; padding: 5px; display: inline-block;"> Aut Spd:+0.8kts  use Set / Spd </div>  	<p>1<sup>st</sup> line:  - Current reference value of the log</p> <p>2<sup>nd</sup> line:  - Request to switch-over to manual value input (refer to [2]) or to remain in the automatic value input (<b>Set</b> key)</p>
[2] Switching-over the Operating Mode	 <div style="border: 1px solid black; padding: 5px; display: inline-block;"> Man Spd:+0.9kts  use ^ v Set / Spd </div>  	<p>1<sup>st</sup> line:  - Last manually entered reference value</p> <p>2<sup>nd</sup> line:  - Request to accept the displayed value (refer to [4]) or to accept a new value (refer to [3] and [4])</p>

	<b>Indications</b>	<b>Comments, Notes</b>
<b>[3] Changing values</b>		
 or: 	<p>Limit values 'Speed'          upper: + 90.0 kn          lower: - 90.0 kn</p>	<p>Changing values (can be read-off at LCD display):</p> <ul style="list-style-type: none"> <li>- stepwise by short actuation</li> <li>- continually by long actuation</li> </ul> <p>If, after 7 s, these keys or the key <b>Set</b> are not actuated, then the yellow LED goes out and the system returns to its initial condition.</p> <p>Values outside of the limit values cannot be set.</p>
<b>[4] Accepting Values</b>		<p>Accepting values and thereby switching-over to manual reference value input for the speed-error correction</p> <p>Indication of the current, corrected heading value of the gyro compass.  <b>Man</b> signalizes selection of the manual reference value input.</p>

**Gyro Compass Equipment STANDARD 20 COMPACT**  
**with Speed-error Correction**  
**Operator Manual**

---

### 6.3.2

### Switching-over from Manual to Automatic Reference Value Input for the Speed-error Correction






For an optimal speed-error correction the reference values of the sensors must be correct.

Before switching-over to automatic reference value input operating mode, the sensor values must therefore be checked.

#### 1.1.1.1.1

#### Reference Value for Latitude (Lat.)

	Indications	Comments, Notes
1	<p>Calling up the Operation Mode</p> 	<p>1<sup>st</sup> line:            - Last manually entered reference value</p> <p>2<sup>nd</sup> line:            - Request to switch over to automatic value input (refer to 2) or to remain in manual value input (key Set)</p>
2	<p>Switching-over the Operating Mode</p>   	<p>1<sup>st</sup> line:            - Current reference value of the position receiver</p> <p>2<sup>nd</sup> line:            - Request to switch-over to automatic value input (refer to 3) or to remain in manual value input (key Lat)</p> <p>Position receiver not ready for operation            - Switching-over not possible            - Display of the last received reference value</p>





	Indications	Comments, Notes
③ Accepting the Operating Mode	  <div style="border: 1px solid black; padding: 2px; display: inline-block;">G1: 153.7°</div> 	Indication of the current, corrected heading value of the gyro compass

#### 6.3.2.1 Reference Value for Speed (Spd.)

	Indications	Comments, Notes
① Calling up the Operation Mode	 <div style="border: 1px solid black; padding: 2px; display: inline-block;">Man Spd:+0.9kts use ^ v Set / Spd</div>  	<p>1<sup>st</sup> line:        - Last manually entered reference value</p> <p>2<sup>nd</sup> line:        - Request to switch over to automatic value input (refer to ②) or to remain in manual value input (key <b>Set</b>)</p>
② Switching-over the Operating Mode	 <div style="border: 1px solid black; padding: 2px; display: inline-block;">Aut Spd:+0.8kts use Set / Spd</div>    <div style="border: 1px solid black; padding: 2px; display: inline-block;">Aut Spd:+00.0kts Not connected</div> 	<p>1<sup>st</sup> line:        - Current reference value of the log</p> <p>2<sup>nd</sup> line:        - Request to switch-over to automatic value input (refer to ③) or to remain in manual value input (key <b>Speed</b>)</p> <p>Log not ready for operation        - Switching-over not possible        - Display of the last received reference value</p>

**Gyro Compass Equipment STANDARD 20 COMPACT**  
**with Speed-error Correction**  
**Operator Manual**

	<b>Indications</b>	<b>Comments, Notes</b>
<b>③ Accepting the Operating Mode</b>		
		Indication of the current, corrected heading value of the selected gyro compass



## 6.4 Additional Operations in Normal Mode

### 6.4.1 Calling up the Uncorrected Heading Value



	<b>Indications</b>	<b>Comments, Notes</b>
		Indication of the uncorrected heading value whilst key is being pressed

### 6.4.2 Calling up the Current Reference Values (Lat. und Spd.)


	<b>Indications</b>	<b>Comments, Notes</b>
	 oder: 	 In automatic value input operating mode for the speed-error correction: - Current reference value of the sensors
	 oder: 	 In manual value input operating mode for the speed-error correction: - Last manually inputted reference value
		Switching back to display of the heading value

**Gyro Compass Equipment STANDARD 20 COMPACT**  
**with Speed-error Correction**  
**Operator Manual**



#### 6.4.3 Dimming

	<b>Indications</b>	<b>Comments, Notes</b>
   or: 	<p>e.g.:          ⇒ </p> <p>or:</p> <p>⇒ </p>	<p>Continuous brightness adjustment</p> <ul style="list-style-type: none"> <li>- of the key illumination</li> <li>- of the LEDs (apart from alarm LED)</li> <li>- of the background illumination of the LCD display</li> </ul>

#### 6.4.4 Contrast Adjustment of the LCD Display

	<b>Indications</b>	<b>Comments, Notes</b>
   or: 		<p>After approx. 2 s, automatic switching back to heading display, if no key is pressed</p>

#### 6.4.5 Test

	<b>Indications</b>	<b>Comments, Notes</b>
   simultaneously	<p>↓</p> <p>Begin of Test</p>  <p>↓</p> <p>e. g.: Software Version 130-602P01E00.01</p> <p>↓</p> <p>End of Test</p> 	<p>Automatic test run for approx. 5 s</p> <p>Check of</p> <ul style="list-style-type: none"> <li>- the LCD segments</li> <li>- the acoustic signalling</li> <li>- the LEDs at max. brightness</li> <li>- the key illumination at max. brightness</li> </ul> <p>After completion of test, automatic switch-back to heading display.</p>

## 6.5 Warnings by Events at the Gyro Compass



The function of the gyro compass equipment is not restricted when warnings occur!

A possible breakdown can be avoided by correcting the fault in a timely manner.

		Indications	Comments, Notes
<b>[1]</b>	Signalling		
		<b>c</b> flashes	Indication ( <b>c</b> = caution)
<b>[2]</b>	Calling up the Cause of the Warning		
			Indication of the cause of the warning whilst pressing the key.  If several warnings are waiting then these are displayed one after the other whilst the key is pressed.
<b>[3]</b>	Corrective Measures Refer to Description No. 110-800.DOC032		

Survey of possible warnings:

Display on Gyro Compass	Display on Operator Unit	Description
c1	Warn: Fan	Ventilator, function inhibited
c2	Warn: Heating	Heating, function inhibited
c3	Warn: Temp > 65 °C	Temperature of supporting liquid > 65 °C
c4	Warn: Temp Contr.	Temperature regulator, function inhibited
c5	siehe Abschn. 7.2.1	Interruption of supply voltage at a supporting liquid temperature $\geq 45^{\circ}\text{C}$ (compass internal follow-up switched on)
c6 *)	Warn: Height	Height of gyrosphere out of tolerance

\*) Valid from software version P02 E02.02

After the cause of the warning has been corrected, the flashing **c** automatically goes out.

**Gyro Compass Equipment STANDARD 20 COMPACT  
with Speed-error Correction  
Operator Manual**

---









## 7

### Fault Operation

The equipment is operating faultily when it determines a fault via its permanent self test and emits an alarm message.

#### 7.1 Survey of Alarms on the Components of the Equipment

	Operator Unit	Gyro compass	Repeater Compass
- Fault in gyro compass	 and  flashes <div style="border: 1px solid black; padding: 2px; display: inline-block;">           Fault name         </div>	 E1 - E9	 (red)
- System fault	 and  flashes <div style="border: 1px solid black; padding: 2px; display: inline-block;">           Fault name         </div>	 current heading value	 (red)
- Fault in repeater compass (refer to Description no. 133-555.DOC012, Section 6 or 133-556.DOC012, Section 6)	-	-	 (red) or:  



Refer to the respective equipment manuals for the behaviour of other system components when in fault operation and the measures to be taken in these cases.


**Gyro Compass Equipment STANDARD 20 COMPACT  
with Speed-error Correction  
Operator Manual**

---

**7.2**

**Procedure in Case an Alarm occurs**

- Occurrence of an alarm




and

- Acknowledge an alarm with



(audible alarm ceases, LED shows continuous light)

- Call up fault name with



(whilst pressing the key)

- Immediately take the following measures

- switch-over to available redundant operating modes (manual reference value, if still possible; navigation with magnetic compass)
- fault correction with means on-board ship (replacement parts), or
- contact ANSCHÜTZ Service.

To help you to react quickly in case of a fault, the following chapters are constructed as follows:




- Alarm survey 7.2.1 shows at a glance all possible alarm signallings and conditions after acknowledgement
- Fault list 7.2.2 contains the fault names in alphabetical order





### 7.2.1 Survey of Alarms

Alarm display	Display after acknowledgement	Call up fault name	Comments
 and flashes <div style="border: 1px solid black; padding: 2px; display: inline-block;">           Fault name         </div>	 and <div style="border: 1px solid black; padding: 2px; display: inline-block;">           G1: 120.5° E         </div>	<div style="border: 1px solid black; padding: 2px; display: inline-block;">           Fault name         </div>	Refer to fault list Section 7.2.2
 and flashes <div style="border: 1px solid black; padding: 2px; display: inline-block;">           Fault name         </div>	 and <div style="border: 1px solid black; padding: 2px; display: inline-block;">           G1: not avail.E         </div>	<div style="border: 1px solid black; padding: 2px; display: inline-block;">           Fault name         </div>	Fault names are listed in alphabetical order

## Survey of Alarms (Cont.)

Display	Acknowledgement	Signification	Possible Cause	Effect on Operation	Measures				
 and  flashes  Check Values	 and   e. g.: <table border="1"><tr><td>G1: 127.3°</td></tr><tr><td>G2: Stdby (153.5°)</td></tr></table> Display of current system condition	G1: 127.3°	G2: Stdby (153.5°)	Request to check the inputted values - configuration in the service mode	Fault in data storage, system executes initial start	Initial start results in all manually inputted values are set to 0 operating mode 'gyro compass operation' with automatic reference value input is selected the configuration in the service mode is set to default values	Select oper. mode suited to the system configuration and input new reference values, if necessary. (Refer to service manual 'Gyro Compass Equipment STANDARD 20 COMPACT')		
G1: 127.3°									
G2: Stdby (153.5°)									
 and  flashes  Check Values	 and   <table border="1"><tr><td>Ext. Pos. Error</td></tr><tr><td>or</td></tr><tr><td>Ext. Spd. Error</td></tr></table> After further acknowledgement: <table border="1"><tr><td>G1: 127.3° uncor E</td></tr></table>	Ext. Pos. Error	or	Ext. Spd. Error	G1: 127.3° uncor E	GPS and/or Log fault, causing failure of the speed error correction. Request to check the configuration in the service mode	Gyro compass system executes initial start; GPS or log failure shortly before the beginning of or during the initial start, or when GPS and log are not yet available.	Initial start results in all manually inputted values are set to 0 operating mode 'gyro compass operation' with automatic reference value input is selected Now the <b>uncorrected heading</b> is transmitted to all connected receivers. the configuration in the service mode is set to default values	Make GPS or Log ready for operation Select oper. mode suited to the system configuration and situation and input new reference values, if necessary. (Refer to service manual 'Gyro Compass Equipment STANDARD 20 COMPACT')
Ext. Pos. Error									
or									
Ext. Spd. Error									
G1: 127.3° uncor E									
 and   NO CONNECTION	 and   <table border="1"><tr><td>NO CONNECTION</td></tr></table>	NO CONNECTION	Data connection between distributor COMPACT and operator unit interrupted	Cable connection, plug contacts Computer break down	Acc. to scope of fault only operator unit display is effected all displays no longer follow the heading change	Check cable connection and plug contacts Exchange distribution PCB in the distributor COMPACT (refer to service manual No. 110-224.NG002.DOC032)			
NO CONNECTION									

## Survey of Alarms (Cont.)

Display	Display after Acknowledgement	Signification	Possible Cause	Effect on Operation	Measures
 and 	 and  NO TELEGRAMS	Missing or faulty telegram from distributor COMPACT to operator unit  NO TELEGRAMS	Computer error  Fault during data transmission	Acc. to scope of fault • only operator unit display is effected • all displays no longer follow the heading change	<ul style="list-style-type: none"> <li>in total break down, select emergency operation</li> <li>Fault search / correction</li> <li>(refer to service manual 'Gyro Compass Equipment STANDARD 20 COMPACT')</li> </ul>
After pressing the flashing key <b>Set:</b> <input type="checkbox"/> not accepted	Momentary, then back to initial setting	inapplicable, as no alarm signalling	Data not accepted	New values not accepted	Repeat procedure
 and  flashes	G1: Volt. Interr.	 and  G1: 127.3° NSet	Gyro compass in settling phase (refer also to 6 [4])	Displayed heading value still imprecise and not usable	<ul style="list-style-type: none"> <li>Read-off heading information directly from magnetic compass</li> </ul>

## 7.2.2 Fault List

No.	Fault Name	Signification	Possible Cause	Effect on Operation	Measure
1	Encoder	Gyro Compass Fault E3	Encoder fault	Gyro compass supplies no heading values, displays no longer follow the heading change	Refer to fault no. 5/6
2	Ext. Gyro supply	System Fault Breakdown in supply voltage for the gyro compass	DC / DC converter in the distributor COMPACT is defective; wiring fault	Gyro compass supplies no heading values	<ul style="list-style-type: none"> <li>• Read-off heading information directly from the magnetic compass</li> <li>• Fault search, fault correction (refer to service manual 'Gyro Compass Equipment STANDARD 20 COMPACT')</li> </ul>
3	Extern Pos Error	System Fault Breakdown in position reference	Position receiver defective or not switched on; wiring fault	Only operator unit indication is affected; the heading value indication for the repeater compasses remains valid! Speed error correction operates with the last valid value of the position receiver.	<ul style="list-style-type: none"> <li>• Make position receiver ready for operation (refer to equipment manual 'Position Receiver')</li> <li>• Input current latitude values manually (refer to 6.3.1.1)</li> <li>• Fault search, fault correction (refer to equipment man. 'Position Receiver')</li> </ul>
4	Extern Spd Error	System Fault Breakdown in speed reference	Log defective or not switched on; wiring fault	Only operator unit indication is affected; the heading value indication for the repeater compasses remains valid! Speed error correction operates with the last valid value of the position log.	<ul style="list-style-type: none"> <li>• Make log ready for operation (refer to equipment manual 'Log')</li> <li>• Input current speed values manually (refer to 6.3.1.2)</li> <li>• Fault search, fault correction (refer to equipment manual 'Log')</li> </ul>
5	Follow-up	Gyro Compass Fault E5	Gyro Compass internal Follow-up faulty	Gyro compass supplies no heading values, displays no longer follow the heading change	<ul style="list-style-type: none"> <li>• Try a restart by switching off/on, or:</li> <li>• Read-off heading information directly from the magnetic compass</li> <li>• Fault search, fault correction (refer to service manual No. 110-800.DOC032)</li> </ul>
6	Gyro current	Gyro Compass Fault E4	Gyro current faulty	Displays no longer follow the heading change	<ul style="list-style-type: none"> <li>• Try a restart by switching off/on, or:</li> <li>• Read-off heading information directly from the magnetic compass</li> <li>• Fault search, fault correction (refer to service manuals 110-800.DOC032 and 3099E.DOC032)</li> </ul>
7	Gyro Error	System Fault Breakdown in data transfer from gyro compass to distributor COMPACT	Breakdown in gyro compass in cable connection between compass and distributor COMPACT or fault in distributor COMPACT	Displays no longer follow the heading change	<ul style="list-style-type: none"> <li>• Try a restart by switching off/on, or:</li> <li>• Read-off heading information directly from the magnetic compass</li> <li>• Fault search, fault correction (refer to service manuals 110-800.DOC032 and 3099E.DOC032)</li> </ul>

No.	Fault Name	Signification	Possible Cause	Effect on Operation	Measure
8	Gyro Supply	<b>Gyro Compass Fault E2</b>	Gyro supply faulty		
9	Heating	<b>Gyro Compass Fault E8</b>	Breakdown in heating		
10	Height Gyroph.	<b>Gyro Compass Fault E7</b>	Height of the gyroshpere outside of tolerance	Gyro compass supplies no heading values, displays no longer follow the heading change	<ul style="list-style-type: none"> <li>• Try a restart by switching off/on, or:</li> <li>• Read-off heading information directly from the magnetic compass</li> <li>• Fault search, fault correction (refer to service manual 110-800.DOC032)</li> </ul>
11	Operating Volt.	<b>Gyro Compass Fault E1</b>	Operating voltage in compass is faulty		
12	Overtemp. >70°C	<b>Gyro Compass Fault E9</b>	Overtemperature > 70 °C		
13	Temp. sensor	<b>Gyro Compass Fault E6</b>	Temperature sensor breakdown		

**Gyro Compass Equipment STANDARD 20 COMPACT  
with Speed-error Correction  
Operator Manual**

---