
























User Manual




Model No: CL-S001


Parts List:

<div>A</div> <div></div> <div>x1</div>		<div>C</div> <div></div> <div>x1</div>	
<div>B</div> <div></div> <div>x1</div>	<div>D</div> <div></div> <div>x2</div>	<div>E</div> <div></div> <div>x4</div>	<div>F</div> <div></div> <div>x1</div>
<div>G</div> <div></div> <div>(M8*50)x2</div>	<div>H</div> <div></div> <div>(M4*6)x15</div>	<div>I</div> <div></div> <div>(M4*15)x8</div>	<div>J</div> <div></div> <div>x2</div>
<div>K</div> <div></div> <div>(M6*10)x5</div>	<div>L</div> <div></div> <div>x1</div>	<div>M</div> <div></div> <div>x1</div>	<div>N</div> <div></div> <div>x1</div>
<div>O</div> <div></div> <div>x1</div>	<div>P</div> <div></div> <div>(5#)x1</div>	<div>Q</div> <div></div> <div>x1</div>	<div>R</div> <div></div> <div>(ST4*20)x6</div>
<div>S</div> <div></div> <div>x1</div>	<div>T</div> <div></div> <div>(3#)x1</div>	<div>U</div> <div></div> <div>(M4*5)x4</div>	<div>V</div> <div></div> <div>(2#)x1</div>


Usage Modes



Mode:1





Mode:2




Mode:3


Mode: 1




Mode: 1




Mode: 1



Mode: 1





Mode: 2




Mode: 2

6




Mode: 3




Mode: 3


8




A



Mode: 3





Door thickness:40MM









9




M








 ——— Tap to set the PULSE  increase and  to decrease and "OK" to confirm.

 ——— Tap to set the TIME  increase and  to decrease and "OK" to confirm.


 ——— Tap to set NIR  increase and  to decrease and "OK" to confirm.

 ——— Tap to set RED  increase and  to decrease and "OK" to confirm.


 ——— Function increases

 ——— Function decreases

 ——— Function switch, Voice on/off

 ——— Press OK to run after setting

 ——— Press and hold for 3 seconds to turn it on/ off.



Voice instruction content

Wake up the machine instructions:

Hello Cutie

Red light setting brightness instructions:

Red light zero

Red light ten percent

Red light twenty percent

Red light thirtypercent

Red light forty percent

Red light fifty percent

Red light sixty percent

Red light seventy percent

Red light eighty percent

Red light ninety percent

Red light one hundred percent

Infrared light setting brightness instructions:

Infrared light zero

Infrared light ten percent

Infrared light twenty percent

Infrared light thirty percent

Infrared light forty percent

Infrared light fifty percent

Infrared light sixty percent

Infrared light seventy percent

Infrared light eighty percent

Infrared light ninety percent

Infrared light one hundred percent

The parameters set for machine operation instructions:

Operation

Running machine stop instructions:

Stop

Volume control instructions:

Volume up

Volume down

Voice function switch instructions:

Turn off voice function

Turn on voice function

Run time settings instructions:

Ten minutes

Twenty minutes

Thirty minutes

Forty minutes

Fifty minutes

Sixty minutes

Voice instruction content

Frequency regulation instructions:

Zero Hertz	Twenty one Hertz
One Hertz	Twenty two Hertz
Two Hertz	Twenty threeHertz
Three Hertz	Twenty four Hertz
Four Hertz	Twenty five Hertz
Five Hertz	Twenty six Hertz
Six Hertz	Twenty seven Hertz
Seven Hertz	Twenty eight Hertz
Eight Hertz	Twenty nine Hertz
Nine Hertz	Thirty Hertz
Ten Hertz	Thirty one Hertz
Eleven Hertz	Thirty two Hertz
Twelve Hertz	Thirty three Hertz
Thirteen Hertz	Thirty four Hertz
Fourteen Hertz	Thirty five Hertz
Fifteen Hertz	Thirty six Hertz
Sixteen Hertz	Thirty seven Hertz
Seventeen Hertz	Thirty eight Hertz
Eighteen Hertz	Thirty nine Hertz
Nineteen Hertz	Forty Hertz
Twenty Hertz	

Possible problems and solutions:

1. No voice response:

Check and see if the device is on mute, unmute it by command "Turn on voice function"

Check and see if the machine is running, it needs to be waked up by "Hello Cutie" and commanded to "STOP".

Try again with more accurate pronunciation / speak more slowly.

Restart.

2. The light is not on: Please check whether the power supply is connected.

3. The red light doesn't hurt the eyes, but we suggest you wear an eye mask because it is bright.

Contact us

Website: www.errayhealing.com

E-mail: info@errayhealing.com

Tel: +86 755-29108212

Fax: +86 755-29108212

Mobile: +86 19820224486

Add: 1st Floor, Building 2, No. 9, Lane 1, Yuanling Industrial Zone, Shangwu

Community, Shiyan Street, Bao'an District, Shenzhen