





User Manual




Model No: CL-F001


Parts List:

<p>A</p>  <p>x1</p>	<p>B</p>  <p>x1</p>		
<p>C</p>  <p>x1</p>	<p>D</p>  <p>x1</p>	<p>E</p>  <p>x2</p>	<p>F</p>  <p>x1</p>
<p>G</p>  <p>x1</p>	<p>H</p>  <p>x1</p>	<p>I</p>  <p>x1</p>	

User Guide:





Mode: 1




Mode: 2

Mode: 1


Adjustable angle





Mode: 2




Mode: 2



Thickness of door 40MM





—— Tap to set RED,  increase and  to decrease and "OK" to confirm



—— Tap to set NIR,  increase and  to decrease and "OK" to confirm



—— Function increases




—— Function decreases



—— Tap "SET" to enter Pulse/Time setting  to increase and  to decrease, "OK" to confirm



—— Press "OK" to run after setting



Voice instruction content

Wake up the machine instructions:

Hello Cutie

Red light setting brightness instructions:

Red light zero

Red light ten percent

Red light twenty percent

Red light thirtypercent

Red light forty percent

Red light fifty percent

Red light sixty percent

Red light seventy percent

Red light eighty percent

Red light ninety percent

Red light one hundred percent

Infrared light setting brightness instructions:

Infrared light zero

Infrared light ten percent

Infrared light twenty percent

Infrared light thirty percent

Infrared light forty percent

Infrared light fifty percent

Infrared light sixty percent

Infrared light seventy percent

Infrared light eighty percent

Infrared light ninety percent

Infrared light one hundred percent

The parameters set for machine operation instructions:

Operation

Running machine stop instructions:

Stop

Volume control instructions:

Volume up

Volume down

Voice function switch instructions:

Turn off voice function

Turn on voice function

Run time settings instructions:

Ten minutes

Twenty minutes

Thirty minutes

Forty minutes

Fifty minutes

Sixty minutes

Voice instruction content

Frequency regulation instructions:

Zero Hertz

One Hertz

Two Hertz

Three Hertz

Four Hertz

Five Hertz

Six Hertz

Seven Hertz

Eight Hertz

Nine Hertz

Ten Hertz

Eleven Hertz

Twelve Hertz

Thirteen Hertz

Fourteen Hertz

Fifteen Hertz

Sixteen Hertz

Seventeen Hertz

Eighteen Hertz

Nineteen Hertz

Twenty Hertz

Twenty one Hertz

Twenty two Hertz

Twenty three Hertz

Twenty four Hertz

Twenty five Hertz

Twenty six Hertz

Twenty seven Hertz

Twenty eight Hertz

Twenty nine Hertz

Thirty Hertz

Thirty one Hertz

Thirty two Hertz

Thirty three Hertz

Thirty four Hertz

Thirty five Hertz

Thirty six Hertz

Thirty seven Hertz

Thirty eight Hertz

Thirty nine Hertz

Forty Hertz

Possible problems:

1.No voice response:

Check and see if the device is on mute,unmute it by command "Turn on voice function"

Check and see if the machine is running, it needs to be waked up by "Hello Cutie" and command to STOP"

Try again with more accurate pronunciation/speak more slowly.

Restart



2.The light is not on:please check whether the power supply is connected.

3.The red light doesn't hurt the eyes,but we suggest you wear an eye mask because it is bright.

Contact us

Website: www.errayhealing.com

E-mail: info@errayhealing.com

Tel: +86 755-29108212

Fax: +86 755-29108212

Mobile:+86 19820224486

Add: 1st Floor, Building 2, No. 9, Lane 1, Yuanling Industrial Zone,Shangwu

Community, Shiyan Street, Bao'an District, Shenzhen