



## Fully Automatic Blood Pressure Measure Sphygmomanometers With Spo2 Measure Function

Easily master Fully Automatic Blood Pressure Measure Sphygmomanometers With Spo2 measure function. PINMED strive for excellence, Just to get your attention. Blood oxygen saturation (SaO<sub>2</sub>) is the percentage of the volume of oxygen-bound oxygenated hemoglobin (HbO<sub>2</sub>) in the blood as a percentage of the total binding hemoglobin (Hb). It is the concentration of blood oxygen and is an important physiological parameter of respiratory circulation.

Customized Fully Automatic Blood Pressure Measure Sphygmomanometers With Spo2 Measure Function From China

### 1. Parameter (Specification) of Fully Automatic Blood Pressure Measure Sphygmomanometers With Spo2 measure function

- a) )The Electronic Sphygmomanometer store the measure results of three users automatically, and up to 100 items for every user
- b) Three kinds of measure modes: adult, pediatric and infant.
- c) By data review interface such as "data list", "trend graph", "big font", NIBP data is clear at a glance
- d) With Spo2 measure function (with optional Spo2 probe)
- e) physiological alarm
- f) Screen displays prompt message when the power is low
- g) With short-time power storage function
- h) Supply two kinds of NIBP measure unit: mmHg/kPa



i)Store measure results with date and time

j)High-definition color LCD display

## 2. How to use Fully Automatic Blood Pressure Measure

### Sphygmomanometers With Spo2 measure function?

- 1.Relax about 5-10 minutes before measuring.Without eating, drinking alcohol, smoking, and bathing for 30 minutes before taking measurements;
- 2.Roll upthe sleeve but not too tight;
- 3.Remove watch or otherthing from the arm;
- 4.Please make sure the blood pressure monitor is on the same level with heart.
- 5.Don't bend over or cross your legs or talkingduring the measurement, until measurement is complete.

## 3. FAQ of Fully Automatic Blood Pressure Measure

### Sphygmomanometers With Spo2 measure function

Q:What's the transportation way?

A:DHL,TNT,FEDEX,UPS,EMS, By sea or By Air.

Q:How long it will be to get samples?

A:7-10 days for general products, 15-25days for customized products.



[www.pinmed.cn](http://www.pinmed.cn)

Q:If OEM is acceptable?

A:Yes,we will try our best to satisfy your demand.

## COMPANY PROFILE

Ningbo Pinmed Instruments Co., Ltd.



Ningbo PINMED Instruments Co., Ltd. which founded in 2015 is located in the beautiful sea port city, Ningbo. And we are focus on the top quality of medical products to introduce to global customer.



Our company offers variety of products which can meet multifarious demands.





TRANSPORTATION  
Ningbo Pinmed Instruments Co., Ltd.



We offer a variety of transportation methods.