

SouKen

Food Waste Garbage Processor Disposal Crusher

The kitchen garbage disposer is a cleaning device that grinds and pulverizes food residues to powder or small particles by high-speed motor-driven grinding parts and is naturally discharged with water and sewer. It can effectively dispose of various food wastes in the kitchen, such as: Small pieces of pork bones, chicken bones, fish bones, egg shells, melon skin, fruit kernels, tea leaves, vegetable root leaves, coffee grounds, leftovers, residues, bread crumbs, etc., crushed and ground into a paste-like liquid, through The pipe is naturally discharged with water to achieve a clean environment and eliminate odors. It can reduce kitchen odor, reduce pest harassment and promote family health.

parameter

Model	SS-8550DB
Application	Home Use
Input Power	550W
Horsepower	3/4 HP
Voltage	110V/220V
Current	3.25A
Frequency	50/60Hz
Rated Rotary Speed	3200-3600RPM
Motor	Permanent Magnetic DC motor
Grinding Capacity	1000ML
Grinding System material	Stainless steel
Safety protection	Overcurrent & overload protection
optional sink connector	140mm,160mm,180mm
Sound-proof system	Double hollow structure
ON/OFF	Air Switch
Number of users	6-9 People
Warranty	2 years
standard life	8-10 years
Weight	5.1KG
Size	410mm(H) x 220mm(W)

Things to be aware of when using the operation:

1. Before starting the machine, check whether the parts are flexible, intact, and free from collision noise. The fasteners are firm and reliable, and all parts of the electrical appliances can be used normally.
2. It is not allowed to put metal blocks, bottle caps, glass, ceramics, large pieces of hard bones, hard shells and other difficult things to deal with.
3. Always check for leakage or water leakage.
4. After each treatment, there may be piecemeal garbage in the garbage hopper, and the water will be washed away downwards. It is not allowed to use metal or hard rod to break into the garbage hopper.


5. After each treatment, if there are a small amount of vegetable ribs and residues left in the sieve circle, the next treatment will not be affected. When the amount of hard waste is large, the input should be dispersed. When dealing with vegetable garbage for a long time, it is better to mix it with Baker.



The kitchen is ground to foam
Refuse clogging of sewer



Locking hose
Waterproof bed bug



Prevent bacterial growth
Family health and worry

EASY TO OPERATE JUST THREE STEPS



1. Open the tap



2. Start smart switch




3. Pour food waste

Easier garbage disposal

Easily grind fruits, vegetables, eggshells, tea and all kinds of small bones and other leftovers, and experience a clean and fresh kitchen.



STILL WORRIED



NINGBO SUNJOYSAFETY TECHNOLOGY CO.,LTD

Address:No.535 Kangqiao South Road, Ningbo, China

Zip code:315000

Tel:0574-87656294

Fax:0574-87526792

E-mail:sales10@nbshine.com

Website:www.food-waste-disposer.com