

SouKen

Kitchen Food Waste Disposer Garbage Disposal

Kitchen food waste disposer garbage disposal: Also known as the Kitchen food garbage processor, it is installed at the drain of the kitchen sink of the home kitchen, which can conveniently store food such as vegetable head and leftovers. After the kitchen waste is crushed, it is ground into fine particles and discharged into the pipeline.

By changing the form of food waste to timely indiscriminate the treatment of food waste, the food waste can be pulverized into a slurry liquid and discharged directly from the sewage pipe, which can easily realize instant, convenient and quick kitchen cleaning, and avoid food waste due to storage. It can effectively improve the home environment by breeding germs, mosquitoes and odors, and completely solve the problem that the sewers are easily blocked, and significantly improve public environmental sanitation.

Easy to install: convenient and simple, through the installation of video, you will see it in 5 minutes, no need for professionals

parameter

Model	SS-8375DS
Application	Home Use
Input Power	375W
Horsepower	1/2 HP
Voltage	110V/220V
Current	2.25A
Frequency	50/60Hz
Rated Rotary Speed	2800/3200RPM
Motor	Permanent Magnetic DC motor
Grinding Capacity	1000ML
Grinding System material	Stainless steel
Safety protection	Overcurrent & overload protection
optional sink connector	140mm,160mm,180mm
Sound-proof system	Double hollow structure
ON/OFF	Air Swith
Number of users	5-7 People
Warranty	2 years
standard life	8-10 years
Weight	4.4KG
Size	385mm(H) x 218mm(W)

installation steps:

1. Remove the pipe, remove the existing pipe from the sink, and remove the blockage. Unless it is installed in a new house, the drain damper should be removed first, and the pipe should be cleaned with a water pipe dredger. Be sure to clear the connection between the horizontal drain pipe and the sewage pipe.
2. Place the washer, place the rubber washer under the sink flange, and then pass the sink flange through the sink drain. If the sink does not fit the rubber washer, use a hose ash to seal it under the sink flange. The caliber needs to be 90mm. If it does not match, you need to contact the agent to purchase the transfer interface. 1. Install the kitchen food waste disposer before drilling a hole with a diameter of 33MM on the kitchen workbench or the basin, to be drilled in the most convenient use. Place, remove the support nut of the button device, place the button device into the hole just drilled, and screw the support nut.
3. Mount the hook and attach the hook assembly to the sink using the components provided in the box. Further press the rubber washer, metal backing ring and retaining collar against the flange of the sink and tighten the assembly screws until the entire mounting assembly is securely attached to the sink.
4. Install the food waste disposer drain and drain damper. Metal flanges and rubber washers must be placed over the drain head to prevent leakage when installing the drain. Connect the combined drain pipe to the food waste disposer and connect the thyristor. If your kitchen infrastructure has not been completed, you can reserve power and switch, thus eliminating the cost of this switch.
5. Make a connection, connect the garbage disposal machine and the pendant group, and use the "quick lock" to attach the mechanism. Use a 6.3mm end wrench (or the included hex wrench) to securely lock the food waste disposer in place.
6. Install the power supply part of the garbage disposal machine and the air switch (the individual models need to be equipped separately). Then cover the sink plug, fill it with water, then remove the plug to let the water drain. If there is leakage, repair it in time, so the food waste disposer can be used.

SAFER AND MORE SECURE



BLADELESS GRINDING, SAFE AND SECURE

01

DEDICATED TO PROTECTING FAMILY SAFETY
COMFORTABLE KITCHEN LIFE



EXCELLENT ONE-PIECE MOLDING PROCESS

02

UNIQUE SHOCK ABSORPTION AND NOISE REDUCTION DESIGN
THE COIN DOES NOT FALL WHEN IT IS IN OPERATION





03

AIR SWITCH FOR EASY AND SAFE OPERATION



INSTALLATION DIAGRAM



A WIDE VARIETY OF ALL-ROUND GRINDING



PEEL



VEGETABLE



MELON



FRUIT CORE



BRITTLE BONE



LEFTOVERS



EGGSHELL



FISH BONE

NINGBO SUNJOYSAFETY TECHNOLOGY CO.,LTD

Address:No.535 Kangqiao South Road, Ningbo, China

Zip code:315000

Tel:0574-87656294

Fax:0574-87526792

E-mail:sales10@nbshine.com

Website:www.food-waste-disposer.com