

CODING INSTRUCTIONS BHT1

Key-Ring 310MHz Remote Control Transmitter

CODE SWITCH LOCATION


OVERHEAD DOOR OPENER

- 1 - Remove 2 screws located at rear of opener & let case hinge down.
- 2 - Locate Grey coloured box and remove window to access program switch



ROLLER DOOR OPENER

- 1 - Remove Box from the wall by lifting off screws
- 2 - Locate Program Switch on rear of box.



CODING

- 1 - With the power on push down on program switch until yellow LED is on & let go of switch
- 2 - Push the button you want to open the door on the new remote - Green LED will blink - push the same button again to confirm - Green LED is now steady.
- 3 - Wait 5 seconds - Yellow LED will go off & programming is complete. Replace window & refit.

BUTTONS 1 - 4 Coded differently so 4 devices can be controlled - ignore symbols on buttons