

# SELECTION GUIDE

Terminal				Coil		Relay type	Contact Form	Switching Current (A)										
PCB	Plug-in	QC	Other	DC	AC			0	5	10	15	20	25	30	40	80	100	
						P												
			SMT			PS												
						NX												
						M4	2C											
						M4S												
						M1B												
						M1BS												
						JRC-23F	1C											
						N4100F	1A 1C											
						N4100F-2												
						N4078	2C											
						NG6D	1A											
						JZC-32F	1A 1C											
						JZC-33F	1A 1C											
						NT10	1A											
						N68F	1A 1C											
						JZX-18FF	2C 3C 4C											
						JQX-13F	1C 2A 2B 2C											
						JQX-102F	1A											
						JQX-14FC <sub>1</sub>	1A 1C											
						NT72&NT72-2	1A 1B 1C											
						NT73-2	1A 1B 1C											
						NT73-3	1A 1B 1C											
						NT73-4												
						NT73-4T	1A 1C											
						NT74	1A 1C											
						NT75	1A 1C 2A 2C											
						NT75H	1A 1C											
						NT76	1A 1C											
						NT77	1A											
						JZC-22F	1A 1C											
						JZC-22F <sub>3</sub>	1A 1B 1C											
						JZC-22F <sub>4</sub>	1A											
						NT90	1A 1B 1C											
						NT99	1A 1B 1C											
						NT90(50A)	1A 1B 1C											
						NT90W(65A)	1A 1C											
						NT90T	1A 1B 1C											
						NT99-1	1A 1B 1C											
						NT90T(50A)	1A 1B 1C											
						NT90TP	1A 1B 1C											
						NT90TP(50A)	1A 1B 1C											
						NT98	1A											
						NT90L												
						NT91L	1A 1B 1C											
						NT74L	1A 1C											
						NT75L	1A 1C											
						NT75LT	1A											
						NT95L	1A											
						NT78	1A 1B 1C 1U											
						NV23K&NV23KW	1A 1C											
						NV231	2A 2C											



# SELECTION GUIDE

Terminal				Coil		Relay type	Contact Form	Switching Current	(A)
PCB	Plug-in	QC	Other	DC	AC			0 5 10 15 20 25 30 40 80 100	
■	■			■		4117	1A 1B 1C 1U 1V 1W	20A	
■	■			■		4120	1A 1B 1C	30A	45A
■	■			■		NVF4-1		20A	40A
■	■			■		NVF4-2	1A 1B 1C	20A	40A
■	■			■		NVF4-2a		20A	40A
■	■			■		NVF4-2b		20A	40A
■	■			■		NVF4-3		25A	100A
■	■			■		NVF4-4	1A 1B 1C 1U	25A	100A
■	■			■		NVF4-6	1A 1C	150A	
■	■			■		NVF4-7		70A	
■	■			■		NVF4-8	1A	70A	
■	■			■		NVF6	1A 1C	50A	
■	■			■		NVF7	1A	80A	
■	■			■		NVF8	1A	20A	
■	■			■		NCV	1A	25A	
■	■			■		NVFM	1A 1C	35A	
■	■			■		NVFS	1A	30A	
■	■			■		NVF11	1A	30A	
■	■			■		NVF16	1A 1C	40A	
■	■			■		NVF28	1A 1C	35A	
■	■			■		NG8N & NG8NW	1C 2C	25A(motor)	
■	■			■		NG8QN&NG8QW	1C 2C	20A	

