
尺寸: 140*105MM 正反印刷折页



Product Description

S 10 is a high-performance industrial endoscope camera with 5 inch HD color display. It adopts ergonomic design, which makes it easy to operate. Self-storage, support for photo and video functions, also the TF card expansion function (up to 64G). This product is equipped with a small diameter HD camera with LED auxiliary lighting. The camera adopts a high-sensitivity chip, which can be used normally

- · Do not hit the camera violently and do not pull the cable. · When used in an environment with sharp bumps, please use it carefully toprevent the waterproof protective layer of the probe from being scratched.
- · The camera probe is not made of heat-resistant and high-temperaturematerials. When checking the automobile engine, please ensure that thetemperature in the engine drops to the normal emperature.
- · When not in use, please ensure that the lens and the main unit are clean anddry, and avoid contact with oil, etc. or other corrosive and dangerous substances.
- This product is not suitable for people with limited physical, sensory

- · Please use a 5V household charger that meets the safety regulations tocharge the equipment. Fast charging is not supported.
- · This device supports charging while using. · If the device is not used for a long time, please ensure that it is
- caused by excessive discharge of the battery.

even in a dark working environment.

Safety and Maintenand

- · The product is an industrial endoscopy camera and is not intended
- formedical use or human examination.

- ormental abilities.
- · Do not allow children to touch and operate this equipment.
- Battery instruction:
- charged atleast once every 3 months to prevent irreparable damage
- 8.Lens Steering Control knob

photo album

1.Setting key: ①Enter ②Exit the setting interface

③Video playback fast forward key ④Zoom in

4.Switch: (1)Press and hold for 3 seconds to turn on / off

(3)End recording (4)Long press to switch camera


3.Enter: ①Confirm selection ②Image fixed

2.Up selection key: ①Up ②Adjust the brightness of the camera LED


5.Taking photos: ①Short press to take photos ②Short press to take photos


7.Mode switching: ①Switch between 3 function modes of take photo, video and


6.Down selection key: ①Scroll down ②Picture rotation ③Video playback back key



9.Charging interface











to delete the photo or video.

Please insert the TF card in the off state Please pay attention to whether the

insertion direction and front and back sidesof TF card are correct · Do not use excessive force when inserting orpulling out the TF card to prevent damage tothe card slot structur

Language settings

The default language is English, and the system also supports Simplified Chinese, Japanese, English, Korean, French, German, Italian, Spanish, Russian, Polish

① Press " 🚱 " button to enter the setting page

②Select the language setting

③ Press the up and down button to select the desired language Press " OK "to save

Enter the picture outputting interface






Press "M" to switch to take photo Press "M" to switch to photo album or video, press " [্] " to take photo viewing, select the photo or video that you want to view, press " 🖾 "

Copy picture and video files

Can use a tf card to copy directly, or use a type-c cable to connect to computer for copy



When operating the copy, if the machine is not connected to the computer, please restart the machine or plug and unplug the TYPE-C data line. Do not plug and unplug the TYPE-C data cable during the data transmission process, which will cause the data transmission to fail.

Charging Guide

- I. Connect the device to the TYPE-C USB adapter for charging (5V=1A/5V=2A). The product does not support fast charging.
- (1) During the charging process, the power symbol indicates that the charging is in progress;
- (2) When the device is fully charged, the power display shows the full state

1.Lags happened during the photo outputting of the product Please check whether the product has sufficient power, or restart the device, orreassemble the flexible conduit.

2. Product crash, does not output a picture or the screen turns

Please press the reset button on the right side of the device to restart the device.

The best imaging focal length of the product is: 2cm-10cm, please calibrate the distance to the object, or clean the front of the camera with a clean alcohol cloth.

4.Product chargingPlease use 5V=1A/5V=2A charger to charge the device.The product does not supportfast charging.

5.The camera is heat

It is normal for the camera to heat up, especially when the camera LED light is on at the highest brightness. But it does not affect normal use or service life.

Please confirm whether the TF format is FTA32 . If not, please format it and donot recognize it. Please plug and unplug the TF card again

3.Imaging screen is not clear

Turning radius

6.TF card can not be recognized

B Camera

	Dual lens	Single	e lens	Screen type: 5.0-inch color
Camera diameter	8mm	6mm	8mm	Support camer
Camera resolution	2 Megapixels			2 MP
Viewing angle	78°	70	O°	Video resolutio 1280*720
Auxiliary lighting	8+1 Einstellbare Helligkeits-LEDs	8 Einst Helligke		

20-100mm

32mm

Operating temperature: 32°F-113°F(0°C-45°C)	Battery: 2000mAh			
Battery life: 3 hours	Battery charging time: 2.5 hour			
List: endoscope, manual,TYPE-C charging cable				

35mm

Screen resolution: r display 1280 * 720 nera probe resolution: Photo resolution: 1920*1080 TYPE-C charging port

☼
※ C € F © RoHS