

Fish Grill Pan

ADC® Fancy Fish Grill Pan made in China with fish shape is specially designed for cooking fish, many cooks also use it to store food and cook soup. Due to the large and high side, it fits for large cuts of meat such as ham, brisket, or roasts.



Product Description

Classy ADC® Fish Grill Pan allows you to easily cook your fish or seafood on the grill, ensuring it stays tender but retains a subtle smoky flavor. Its high side can be used to marinate fish. Circulates hot air around the food, providing rapid heating, even heating. It has a wide range of applications, such as chips, pizza, bacon, chicken wings, chicken chops, fried fish, vegetables, etc.



Product Information

Product Name:	Fish Grill Pan
Material:	Die Cast Aluminum
Color:	Black(Can be customized)
Coating:	Black non-stick coating (Can be customized)

Lid:	Glass Lid with Heat Resistant Handle(Can be customized)
Bottom:	Induction, Spinning or Normal Bottom
Logo:	Can be customized



Product Specification

Made of aluminum material with non-stick coating, it is not easy to deform and can be easily separated from food.

Easy to clean. Fish Grill Pan made in China will collect any grease, drips or debris to keep the oven hygienic and save you the hassle of cleaning.

Item NO.	Size: (DIA.) x (H)	Packing Detail
XGP-R01	body 32x20.8x10cm lid 31.4x20x4.5cm	4pcs/ctn/43x26x57cm
XGP-R02	body 32x20.8x10cm	6pcs/ctn/44x27x22cm



Order Information

Ningbo ADC Cookware Co.,Ltd.
Tel:+86-574-87714795

Email:xianghai@xianghai.com

Samples :	Available
MOQ:	General,our MOQ is 1,200 pcs per size.
Price Terms:	FOB Ningbo
Payment Term:	T/T or LC at sight
Delivery Time:	45 days after got the deposit
Place Of Origin :	Ningbo, China
OEM/ODM:	Yes,if you provide artwork



Fish Grill Pan Care Notes

Care: Never allow Fish Grill Pan to boil dry or leave an empty pan on a hot burner unattended. Both of these will cause damage to the cooking properties of this pan. While not necessary, cooking with some oil could improve taste of food and make them look more appetizing .

Be sure to use a heat pad, oven mitt or pot holder when moving or removing cookware from or from the stove or oven.

Cooking Surface: Metal utensils, scouring pads and abrasive cleaners should not be used on surfaces.