LINKREST www.linkrest.com



2 Fold Sofa Sleeper Mechanism Everyday Use

LINKREST is one of the professional manufacturers and suppliers of 2 fold sofa sleeper mechanism everyday use in China. The 2 fold sofa sleeper mechanism everyday use adopts the anti tilting system and the riveting method to avoid falling problems caused by safety reasons. Its cross lines cover more space and reduce the droop when sleeping. The shoulder pole tilts from the shoulder to reduce discomfort and achieve healthy sleep.

Product Description

Bi Fold Sofa Sleeper Mechanisms

Use manufacturers and suppliers in China. We realized that sofa sleeper played more and more important roles in the furniture industry, but we will think very hard for continuing impovements such as: how to make seat as comfortable as stationary seat and how to make sleeper as comfortable as bedroom bed; How to save delivery cost both for mechanism and finished sleeper; How to operate simply for end users both manual and power versions; and how to meet all kind of stationary sofa designs ect. Our wide selection of high-quality and technically innovative folding and unfolding sofa bed mechanisms add value to leading upholstery brands both in domestic and international markets.

2 Fold Sofa Sleeper Mechanism Everyday Use Features & Benefits:

- 1. Flat to flat riveted which is less noise and long cycles of test.
- 2. Reduce the height differences between head tube and foot tube for healthy sleeping.
- 3. Reduce the discomfort to the body because shoulder bar is away from shoulder.
- 4. Cross wires cover much more space for less sagging during the sleeping.
- 5. Anti-tilt system is riveted to avoid drop off issue for safety reason.
- 6. Angle rails system can lock the mattress inside firmly for seat comfort.
- 7. Offer air breath deck and high leg version.


That's why we strongly recommend you to convert overnight sleeper 2500# to DF00# series.


LINKREST www.linkrest.com

2 Fold Sofa Sleeper Mechanism Everyday Use Details:

More comfort both sitting and sleeping for operation everyday







Sleeper Assembly Instruction
Tilt frame forward and move sleeper from
bottom into the position,making sure
sleeper remains tied down.
Add the boits in J-slots location and then
carefully remove both ties down.
Add more wood screws on sleeper
mounting plate.

U-shapped support bar

You're supposed to add U-shapped bar in
the end of frame if your customers like to sit
at end of sleeper. But in fact not allow
people sitting at end of sleeper while in
open position.