

# Installation Instruction of Intellectual Electronic Lock

## Installation Instruction

A. Check the door to make sure if it fits for installation. Adopt corresponding measures to solve the problem if not. ( required thickness: 38MM—55MM)

B. Instruct the woodworker to drill holes and make transfers according to the hole drilling chart( see the attached note).

C. Check if the holes are for sizes.

Installing the core of lock and the tapered rod

---Check if the bolts extend and shrink flexibly.

---Check the opening mode of the core, left or right.

---Encase the core, peg it by two tapping screws and use screws to fix the protecting steel.

---The end face of should be flush with the one of the core.

---Enclose the tapered rod from the front. Use 2 hex screws from behind to fix it in the front board of the core. Use the mechanical key from without to open the lock for a test.

Installing the outside body of lock

---Insert the square rod: make the arrowheads horizontal and insert the square rod.

---Aiming at the square rod, install the outside body of lock outside the door. Don't rotate the square rod.

Installing the inside body of lock

---Make the wire terminal inside the door from the square trench of the door;

---Connect the wire terminal to the corresponding socket;

---After fixing the lock by your hand, tight the coupling screws;

---Insert the battery box which is already loaded with batteries into the corresponding position. Check.

---Rotate the inside handle to make sure if the bolts could be driven. If not, check the square rod.

---Check if the bolts could extend and shrink flexibly. Enclose the assurance knob, Check

if the assurance bolt could extend and shrink flexibly. If not, check the reasons and repeat the above operations then.

Check the open performance and the function of locking inside

Install the arc of doorframe according to the lock and tight the screws.

Installation is completed. Check the open function to make sure the open and close is flexibly.

## Correct Card Reading Method

When using cards, you should be aware of correct card reading method, otherwise it may be invalid. The correct method is below:

---Hold the card by your hand and make sure the card face is parallel to the lock body. The center of the card is towards the induction center. The induction distance is 0mm-30mm.

---Put the card away when the blue LED lights. The buzzer will make a sound.

---The buzzer make hurry sounds after reading the card that indicates the card is invalid or not used in correct method.

---You should open the door in 5s after reading the card, or the card will be read renewedly.